






OLED48B5*
OLED55B5*
OLED65B5*
OLED77B5*
OLED83B5*



www.lg.com

PDF



48/55/65/77/83"

The diagram illustrates the correct and incorrect ways to interact with the touch screen. On the left, two figures are shown: one correctly touching the screen with a finger, and another incorrectly using a pen or sharp object. On the right, a diagram of the screen shows that touching the center is correct, while touching the edges is incorrect, as indicated by red 'X' marks and a warning triangle.

Connection Ports and Cables:

- ANT:** Antenna cable.
- OPTICAL DIGITAL AUDIO:** Optical digital audio cable.
- LAN:** Ethernet cable.
- HDMI:** Standard HDMI cable.
- HDMI eARC/ARC:** HDMI cable with eARC/ARC support.
- USB CI+:** USB cable with CI+ module.
- COMMON INTERFACE:** Common interface slot.

Accessories:

- Antenna
- Optical digital audio receiver
- Router
- HDMI receiver/decoder
- USB CI+ module
- Common interface module

